

LAB 4

Configure DHCP within a LAN and outside LAN.

OBSERVATION:

LAB-4

4(A)

Ans. Configure DHCP within a LAN and outside LAN.

(Topology)

```
graph TD; Switch[switch-PT switch 0] --- PC0[PC-PT PC-0]; Switch --- PC1[PC-PT PC-1]; Switch --- PC2[PC-PT PC-2]; Switch --- PC3[PC-PT PC-3];
```

procedures

- * Connect 3 PC's and 1 server to a switch using copper straight through cable.
- * click on server and go to services tab select DHCP and turn on DHCP service.
- * Set the IP address of the static IP address as 10.0.0.2 & click on save button.
- * Before this, set the IP address of server in config tab under fastethernet to 10.0.0.1
- * Next click on PC0 & go to desktop tab, here click on IP configuration. select DHCP here. It will request for an IP address and successfully get the DHCP request also sets the IP address.
- * Repeat this steps for other 2 PC's
- * To send a packet across PC's, go to PC's command prompt and type ping destination

IP address.

P2M6 Output

packet tracer PC command line 10:

PC> ping 10.0.0.3

pinging 10.0.0.3 with 32 bytes of data.

Reply from 10.0.0.3: bytes=32 time=0ms TTL=128

Reply from 10.0.0.3: bytes=32 time=0ms TTL=128

Reply from 10.0.0.3: bytes=32 time=1ms TTL=128

Reply from 10.0.0.3: bytes=32 time=0ms TTL=128

ping statistics from 10.0.0.3

packets sent=4 Received 4, Lost=0 (0% Loss)

Approximate round trip times in ms.

Minimum=0ms, Maximum=1ms, Average=0ms


Observation:-

- * DHCP is used to dynamically assigns an IP address to any device or node.
- * It is a ~~client-server~~ protocol in which servers manage a pool of unique IP addresses & also about client configuration parameters.
- * DHCP enabled clients sends a request to DHCP server when they want to connect to a network.
- * The DHCP server responds to the client request by providing IP configuration information from address pools, previously, specified by a network administrator.

4[B]

Am1-Configure DHCP with a LAN and outside LAN.

Topology:-



Procedure:-

1. Add a router, a switch and 2 PC's to 4.1A) program network & connect the router to both switches.

2. Let the server IP address of server & with the help of server set the first 3 PC's IP address through DHCP.

→ Click on server.

→ go to desktop → IP configuration

→ Add IP address, subnet mask and gateway.

IP address 10.0.0.1

Subnet mask 255.0.0.0

Gateway 10.0.0.20

Step 3:- Configure the router

→ Click on router go to CLI

enable

Router# config t

Router(config)# fastethernet 0/0

Router(config)# ip address 10.0.0.20 255.0.0.0

Router(config-if)# no shut

Router(config-if)# exit

Router(config)# interface fastethernet 1/0

Router(config)# ip address 20.0.0.20 255.0.0.0

Router(config-if)# no shut

Router(config-if)# exit

exit

Routing table

Router# show ip route

(A) c 10.0.0.0/1 is directly connected, fastethernet 0/0

Step 4:- Go to server [DHCP server configuration]

→ select ~~services~~ then go to DHCP

→ set ~~service~~ on

→ set start IP address from (ex. 20.0.0.0) then save.

Step 5:- Then configure the PC's

→ select a PC then desktop - go to IP configure select DHCP.

→ Repeat the same procedure for all other PC's.

Observation

→ DHCP is used to assign IP addresses dynamically to different devices.


→ To assign continuous IP addresses we create a server pool where we assign the starting IP address and a default gateway number.

For PCs under different switches we create a different server pool again & start.


Lee
19/7/23

TOPOLOGY:

PROGRAM 4.1:




PROGRAM 4.2:



OUTPUT:

PROGRAM 4.1:




```
PC0
Physical Config Desktop Custom Interface
Command Prompt
Packet Tracer PC Command Line 1.0
PC>ping 10.0.0.3

Pinging 10.0.0.3 with 32 bytes of data:

Reply from 10.0.0.3: bytes=32 time=0ms TTL=128
Reply from 10.0.0.3: bytes=32 time=0ms TTL=128
Reply from 10.0.0.3: bytes=32 time=1ms TTL=128
Reply from 10.0.0.3: bytes=32 time=0ms TTL=128

Ping statistics for 10.0.0.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

PC>
```



PROGRAM 4.2:

